



VILLAGE OF PINECREST POLICE DEPARTMENT SOUND LEVEL METER USER GUIDE

1. Power On
2. The meter must be configured with the below settings before each use. The settings must be adjusted each time the meter is turned on because the meter does not save the necessary settings after being turned off.

Button

Setting

A/C

dBA

Hi/Lo

Hi

F/S

~~Slow~~ **FAST**

Max/Hold

• *Press Quickly – MAX Mode*

The meter only updates the LCD when a higher reading than the one presently on the display is detected.

[Press Max/Hold button *once* to exit this mode]

• *Press & Hold – Data Hold*

Freezes the display reading.

[Press and *hold* the Max/Hold button to exit this mode]

3. Use

- A. Hold the meter in hand facing the microphone toward the source of the sound to be measured.
- B. View the measurement on the meter's LCD. An indication of OVER means that the measurement is out of range. Toggle the "Hi" (65 to 130dBA) and "Lo" (35 to 100dBA) measurement ranges using the Hi/Lo button. For measurements in the 65 to 100dBA region either range can be used.